

Alinco DJ-500T VFTOM

- V Enter VFO mod if not already there by pressing [C].
- F Enter the frequency from the keyboard.
(for 146.520MHz enter 146520)
- T Enter CTC tone, press [A] then [8] then [B] or [C] to get to menu 1, then press [1] to get to the tone entry. Rotate the Main Dial to the desired tone. Press [#] to complete.
- O Enter Offset. Press [A] then [4] and repeat until the desired offset, +, - or none, appears in the upper center screen. Press [A] then [8] then [B] or [C] to get to menu 11 to set the offset frequency. Use Menu 7 to change the step.
- M Save to memory, press [A] then [C].
The channel number will flash in the lower right of the screen. Rotate the Main Dial to select the desired channel. Press [A] then press and hold [C] until you hear a double beep.

Alinco DJ-500T VFTOM

- V VFO mode [B^].
- F Key In Receive Frequency
- T Tone. [A] then [8]
then [B] or [C] menu 1,
press [1] get to tone entry.
Press [#] to complete.
- O Offset. [A] then [4] and
repeat for offset, +, - none
[A] then [8] then [B] or [C]
menu 11 set the offset. Use
Menu 7 to change the step.
Press [#] to complete.
- M Save. [A] then [C]. The
channel number will flash.
Rotate Main Dial to select.
Press [A] then hold [C] until
you hear a double beep.