

VFTOM cheat Sheet

Courtesy of K6HIV Knute Josifek

VFTOM - WOUXUN KG-UVD1P, 2P and 3P

Turn on HT

V If in Chanel Mode, press [MENU]→[TDR]

F Enter Frequency (RX for repeaters) all 6 digits.

T Enter Tone [Menu] →16 [MENU] use dial to select CTCSS (OFF for Simplex)
Press [MENU] → [EXIT]

O Set Offset [Menu] →23 [MENU] enter offset all 5digits (skip for Simplex).
Press [MENU] → [EXIT]
Set Offset direction [Menu] →24 [MENU] use dial to select +, - or OFF.
Press [MENU] → [EXIT]

M Save to Memory [Menu] →27 [MENU] use dial to select unused channel
Press [MENU] → [EXIT]

Press [MENU]→[TDR] to return to Channel Mode.